





Product & Accessory Guide

HOW TO USE CHART: Stoves are down the column on left. Grill Boxes, Griddles, are across top. Carry Bags and Patio Covers are down the right. Find Stove on left and follow to the right to find a match. Carry Bags for Grill Boxes and Griddles are across the bottom, and found directly below the corresponding Grill Box/Griddle.

		BARBECUE GRILL BOXES / PIZZA OVENS						PROFESSIONAL FLAT TOP GRIDDLES					UNIVERSAL FLAT TOP GRIDDLES			CARRY BAGS for Stoves		PATIO COVERS for Stoves		SIDE SHELVES		
Stove Name / Model #		BB30L	BB100L	BB60X	BB90L	PZ60	PZ90	SG14	SG30	SG60	SG90	SG100	CGG16B	CGG24B	FG16							
	EXPLORER 2 BURNER EX60	✓	✓	✓		✓			✓	✓			✓		✓	✓	CB60UNV RCB60	✓	PC32	✓	LS60	
	PRO 60 2 BURNER DB60	✓	✓	✓		✓			✓	✓			✓		✓	✓	CB60UNV RCB60	✓	PC46			
	YUKON 2 BURNER YK60	✓	✓	✓		✓			✓	✓			✓		✓	✓	CB60UNV RCB60	✓	PC32	✓	LS60	
	OUTDOORSMAN COMBO EX170	✓	✓	✓		✓											✓	CB60UNV RCB60	✓	PC32	✓	LS60
	OUTDOORSMAN HIGH EX280	✓	✓	✓		✓											✓	CB60UNV RCB60	✓	PC32	✓	LS60
	EXPLORER 3 BURNER EX90	✓	✓	✓		✓			✓	✓				✓		✓	✓	CB48	✓	PC48	✓	LS60
	PRO 30 SINGLE BURNER SB30	✓	✓						✓					✓		✓	✓	BB90BAG				
	EXPEDITION 3X TB90LWG		✓		✓		✓				✓	✓	✓	✓	✓	✓	✓	CB90 RCB90	✓	PC42	✓	LS90
	BIG GAS GRILL SPG90		✓		✓		✓				✓	✓	✓	✓	✓	✓	✓	CB90 RCB90	✓	PC42		
	PRO 90 3 BURNER GB90		✓		✓		✓				✓	✓	✓	✓	✓	✓	✓	CB90	✓	PC90		
	TAHOE 3 BURNER TB90LW		✓		✓		✓				✓	✓	✓	✓	✓	✓	✓	CB90 RCB90	✓	PC42	✓	LS90
	SOMERSET II CCH2				✓		✓				✓				✓				✓	PCH2		
	SOMERSET III CCH3				✓		✓				✓	✓		✓	✓	✓			✓	PCH3		
	SOMERSET IV CCH4				✓		✓				✓				✓				✓	PCH4		
	Single Burner System	PRO 30 SINGLE BURNER SB30	✓	✓						✓				✓		✓	✓	BB90BAG				
OUTDOOR COOKER SL30		✓	✓						✓				✓		✓		CB140					
MAXIMUM OUTPUT SH140																	CB140					
UNIVERSAL OUTPUT SHPR																	CB140					
CARRY BAGS for Grill Boxes and Griddles		BB60BAG	BBBAG	CB60UNV	BB90 BAG	CB60UNV	BB90 BAG	SGBMD	SGBMD	SGBXL	SGBLG	SGB40	CB16	SGBLG	CB16							



Product & Accessory Guide

HOW TO USE CHART: Stoves are down the column on left. Grill Boxes, Griddles, are across top. Carry Bags and Patio Covers are down the right. Find Stove on left and follow to the right to find a match. Carry Bags for Grill Boxes and Griddles are across the bottom, and found directly below the corresponding Grill Box/Griddle.

		BARBECUE GRILL BOXES / PIZZA OVENS					PROFESSIONAL FLAT TOP GRILL					UNIVERSAL FLAT TOP GRIDDLES						CARRY BAGS for Stoves	PATIO COVERS for Stoves					
Product Name/Model #		BB30L	BB100L	BB60X	BB90L	PZ90	SG14	SG30	SG60	SG90	SG100	CGG16B	CGG24B	MSG20	FG13	FG16	FG20	FG26						
Tailgating / RV	MVP SPG25																			CB60UNV RCB60	PC25			
	BIG GAS GRILL SPG90		✓		✓	✓	✓			✓	✓	✓	✓				✓			✓	CB90 RCB90	PC42		
Outdoor	OUTDOOR CAMP OVEN COVEN																				CBOVEN			
Camp	CAMP OVEN W/GRILL COVENG																					CBOVEN		
Ovens	PORTABLE OUTDOOR OVEN COJR																					CBCOJR		
Smoke Vaults Systems	SMOKE VAULT 24" SMV24																						PC18	
	SMOKE VAULT 18" SMV18																						PC24	
Mountain Series	RAINIER MS2G																					CBMS		
	RAINIER COMBO MS2GG																						CBMS	
	TETON MS2														✓	✓	✓	✓					CBMS	
	SIERRA MS2PP														✓	✓	✓	✓					CBMS	
Cooking Systems	DENALI MS3G																						CBMS	
	EVEREST MS2HP																✓	✓					CBMS	
	RANGER II BSC40C														✓	✓	✓	✓					BB90BAG	
Tabletop / Camping Stove Systems	RANGER III BSC60C														✓	✓	✓	✓	✓				CB60UNV	
	WEEKENDER DJ60															✓	✓			✓			CB60UNV	
CARRY BAGS for Grill Boxes and Griddles		BB60BAG	BBBAG	CB60UNV	BB90BAG	BB90BAG	SGBMD	SGBMD	SGBXL	SGBLG	SGB40	CB16	SGBLG	SGBLG	CB16	CB16	SGBMD	SGBLG						