


CHIMNEY CAP (1)
PG24-5

PG36CL

UPPER COOKING RACK (2)
PG36SGX-7



CHIMNEY (1)
PG24-6

PG36 LOWER GRATE (1)
PG36-21

LOWER GRATE (2)
PG24-70

DRIP TRAY (1)
PG36SGX-1

SLIDE ROD (2)
PG36SGX-2

M8 NUT (2)

HEAT DEFLECTOR (1)
PG24SG-2

HANDLE (1)
PG24-57

HANDLE BEZEL (2)
PG24-71

HANDLE DEFLECTOR (1)
PG24-58

HANDLE SCREW (2)
PG24-59

UPPER GRATE BRACKET (2)
PG24SG-11

M6 X 15 SCREW (4)

SHELF (1)
PG36CL-1

M6 X 15 BOLT (5)

PULLOUT LOCK (1)
PG24-42

PULLOUT KNOB (2)
PG24-9

PG36 BURNER PULLOUT (1)
PG36-8

GREASE BUCKET (1)
PG24-11

M8 X 20 BOLT (8)

M8 LOCK WASHER (8)

REAR RIGHT LEG (1)
PG36-18

M8 FLANGE NUT (4)

M8 X 60 BOLT (4)

WHEEL (2)
PG24-16

WHEEL AXLE (2)
PG24-66

M10 ACORN NUT (2)

M10 FLAT WASHER (2)

FRONT RIGHT LEG (1)
PG36-19

FRONT LEFT LEG (1)
PG36-17

PG36 SWIVEL CASTER (2)
PG36-7

BOTTOM SHELF (1)
PG36-20

FEED GASKET (1)
PG24-34

HOPPER ASM (1)
PG24XR-1

ST4.2 X 10 SCREW (6)
COVER PLATE (1)
PG36SGX0-1

PROBE COVER (1)
PG24-54

THERMOMETER (1)
PG24-44

PULL ROD (1)
PG24SG-3

LID (1)
PG36SGX-8S

ASH CUP (1)
PG24-17

0119 PG36XR PARTS

