






LEG ASSEMBLY

1. Remove back plate then reattach the hub and back plate to the frame. Tighten with the thumb screws. (12" to 18" from corners)
2. Insert leg into holes at the bottom of the hub.

Note: Screen height can be adjusted by placing the hub higher or lower on the frame.

3. Tie guy lines to the grommets in the top of the screen. Stake the lines down at an angle to secure the screen.



www.outdoorentertainmentgear.com